




QUICK REFERENCE GUIDE











MD110 System Telephones DBC 201, 202, 203

QUICK REFERENCE GUIDE






ANSWER CALLS

- Answer**  Access 1/2 or  Access 1 or 2 or 
- Call Pick-Up** Call the ringing extension **8**






MAKE CALLS

- Normal Calls**  (Dial number)
- Common Abbreviated number**  (Dial abbreviated number)
- Individual Abbreviated Number**   Digit from 0-9
- Speed Dial** 
- Last Number Redial**   


DURING CALLS

- Switch to Handset** 
- Switch to Loudspeaker** 
- Switch to Handsfree**   (DBC 203 only)
- Mute** 

INQUIRY


- Activate**  Call 3rd party
- Refer Back to First Party**  
- Alternate Between Calls**  

TRANSFER



- Transfer to Another Extension** Make inquiry  (Press before or after answer)

QUICK REFERENCE GUIDE

MOUNTING THE FOOT CONSOLES



Adjusting the hook



WALL MOUNTING


Positioning the screws

The telephone is attached with three screws. Use this diagram to mark the position of the screws. DBC 201, 202 are marked in blue, and DBC 203 is marked in yellow.

QUICK REFERENCE GUIDE

ANSWER CALLS

Answer




Call Pick-Up


Call the ringing extension **8**

MAKE CALLS


Normal Calls



Common Abbreviated number




Individual Abbreviated Number



Speed Dial



Last Number Redial



DURING CALLS


Switch to Handset



Switch to Loudspeaker



Switch to Handsfree




Mute




INQUIRY


Activate



Refer Back to First Party




Alternate Between Calls






TRANSFER

Transfer to Another Extension






QUICK REFERENCE GUIDE






ANSWER CALLS

Answer  Access 1/2 or  Access 1 or 2 or 
Call Pick-Up Call the ringing extension **8**





MAKE CALLS

Normal Calls  (Dial number)
Common Abbreviated number  (Dial abbreviated number)
Individual Abbreviated Number *** * *** Digit from 0-9
Speed Dial 
Last Number Redial *** * ***


DURING CALLS

Switch to Handset 
Switch to Loudspeaker 
Switch to Handsfree   (DBC 203 only)
Mute 


INQUIRY

Activate  Call 3rd party
Refer Back to First Party  Access 1
Alternate Between Calls  

TRANSFER

Transfer to Another Extension Make inquiry  (Press before or after answer)



CONFERENCE

Activate  Call 3rd party **3**

WHEN BUSY OR NO ANSWER

Callback
Activate **6**
Cancel One **# 6 * ext. #**
Cancel All **# 6 #**
Call Waiting **5** (At busy signal)

CALL DIVERSION









Diversion All Calls
Activate 
Cancel 
Diversion Override
Activate *** 1 * ext. #**
Follow-Me
Activate *** 2 * new ext. #**
Cancel **# 2 #**
Change *** 2 * own ext. * new ext. #**
Cancel from Answer-Point **# 2 * own ext. #**

External Call Forwarding
Activate *** 2 3 # External No. #**
Cancel **# 2 3 #**
Do Not Disturb
Activate *** 2 7 #**
Cancel **# 2 7 #**







DIVERSION MESSAGE

Activate *** 2 4 * Reason * Time/date #**
Cancel **# 2 4 #**

PROGRAMMING

Individual Abbreviated Dialing
Program *** 5 1 * (0-9) * No. #**
Cancel One **# 5 1 * (0-9) #**
Cancel All **# 5 1 #**
Speed Dial Program   No.  
Cancel   C  

VOLUME CONTROL

Tone Ringer Volume 

Handset Volume (Pick up handset) 

Handsfree/Loudspeaker Volume 


*For Diversion options see the Easy Guide on the back pages.

EASY GUIDE

Tone Ringer Character

Program (0-9) Program

Ring Options

Program Access (0-6) Access Program

- | | |
|-----------------------------|---|
| 0 no ringing (flash only) | 4 flash, two rings, flash |
| 1 normal ringing | 5 immediate speech connection (function key controlled) |
| 2 delayed normal ringing | 6 immediate speech connection |
| 3 two rings then flash only | |

FEATURE

Call Pick-Up

Call Waiting

Callback

Common Hold

Conference

Diversion All Calls

Diversion Message

Diversion Override

Do Not Disturb

External Call Forwarding

Follow Me

Activate

Change

Individual Hold

Inquiry

Last Number Redial

Transfer

ACTIVATION

extension 8

5 (at busy signal)

6

8

Inquiry 3rd party 3

Diversion

* 2 4 * reason * time/date #

* 1 * extension #

* 2 7 #

* 2 3 # ext. no. #

* 2 * extension #

* 2 * own ext. * new ext. #

Access

Inquiry 3rd party

* * *

Inquiry 3rd party Transfer

DEACTIVATION

6

Diversion

2 4

2 7

2 3

2

2 * own ext.

C Access

Ericsson Inc.

Business Systems

1 Triangle Drive

Research Triangle Park, NC 27709

Telephone: (800) 374-2776

EN/LZT 102 2230 RB

© Ericsson Business

Networks AB 1995